



HEAVYWEIGHT
SEDIMENT CONTROL SOLUTIONS
Effective • Durable • Reusable

WTBinc
INNOVATION & INTEGRITY

The Heavyweight HiFlow Tubes™

Installation Instructions



1. When used as a check dam, place in desired location. If more than one tube is needed for damming purposes, place them end to end.
2. When used for drain inlet protection, the tube must be placed closely up against curb to form a tight connection
3. If needing to stack the barrier more than one tube in height, brick layer them so each layer overlaps the gap beneath it.

World Textile and Bag, Inc. (**WTB**) warrants its products to be free from manufacturing defects for 90 days from the date of sale. Any liability during this 90 day period is limited to the cost of the effected products via refund, price adjustment, repair or replacement of the product by standard ground or ocean freight. However, since physical conditions vary from jobsite to jobsite and even within a given jobsite, WTB makes no performance guarantees and assumes no obligation or liability for the reliability or accuracy of information contained herein, for the results, safety or suitability of using our products, or for damages occurring in connection with the installation of any erosion control product whether or not made by WTB or its affiliates, except as separately and specifically made in writing by WTB.