



Temporary Drainage Inlet Protection (Type 4B) Flexible Sediment Barrier (Drawings for Caltrans or DOT flexible sediment barrier, foam barrier 10-1)



Road Slope (percent)	0.0-0.9	1.0-1.9	2.0-2.9	3.0-4.9	5.0+
Angle "A"	70deg	70deg	70deg	45deg	45deg
Spacing	50 ft.	35 ft.	30 ft.	25 ft.	20 ft.



Heavyweight DuraWattle™ Using Hard Surface Application Method

DRAWN	M, MARCEL	WTBinc INNOVATION & INTEGRITY	1627 Main Ave. Suite 4 Sacramento, CA 95838
DESIGNED			
CHECKED			
APPROVED			
DATE	07 NOV 2014	Heavyweight DuraWattle™	
SCALE	NONE	* CONFIDENTIAL *	
SIZE	A	THIS DRAWING IS THE PROPERTY OF THE OWNER. THE INFORMATION HEREIN MAY NOT BE USED OR COPIED WITHOUT THE WRITTEN AUTHORIZATION OF OWNER.	
		DW-45-7.dwg	
		SHEET 1 of 1	



10-1.__ TEMPORARY DRAINAGE INLET PROTECTION - CALTRANS

GENERAL

Summary

This work includes constructing, maintaining, and removing temporary drainage inlet protection. Drainage inlet protection settles and filters sediment before stormwater runoff discharges into storm drainage systems.

The SWPPP must describe and include the use of temporary drainage inlet protection as a water pollution control practice for sediment control.

Provide temporary drainage inlet protection to meet the changing conditions around the drainage inlet. Temporary drainage inlet protection must be:

1. Appropriate type to meet the conditions around the drainage inlet
2. Type 1, Type 2, Type 3A, Type 3B, Type 4, Type 4B, Type 5, Type 6A, Type 6B, or a combination

Submittals

Submit a Certificate of Compliance as specified in Section 6-1.07, "Certificates of Compliance" of the Standard Specifications for:

1. Erosion control blanket
2. Fiber rolls
3. Safety cap for metal posts
4. Silt fence fabric
5. Sediment filter bag
6. Foam barrier
7. Rigid plastic barrier
8. Gravel-filled bag fabric

If you substitute the steel wire staple with an alternative attachment device, submit a sample of the device for approval at least 5 business days before installation.

MATERIALS

Geosynthetic Fabrics

Geosynthetic fabrics for temporary drainage inlet protection must consist of one of the following:

1. Polyester
2. Polypropylene
3. Combined polyester and polypropylene

Geosynthetic fabrics must comply with:

Water Pollution Control

Property	ASTM Designation	Specification				
Application		Silt Fence		Sediment Filter Bag	Gravel-Filled Bags	Foam Barrier
		Woven	Non-woven			
Grab breaking load 1-inch grip, lb, min. in each direction	D 4632	120	120	255	205	200
Apparent elongation percent, min., in each direction	D 4632	15	50	50	50	15
Water Flow Rate max. average roll value, gallons per minute/square foot	D 4491	10-50	100-150	80-200	80-150	100-150
Permittivity 1/sec., min.	D 4491	0.05	0.05	1.5	1.2	0.05
Apparent opening size max. average roll value, U.S. Standard sieve size	D 4751	30	30	20-40	40-80	40
Ultraviolet Degradation percent of original unexposed grab breaking load 500 hr, minimum	D 4595	70				

Foam Barriers

Foam barriers must:

1. Be filled with a urethane foam core
2. Have a geosynthetic fabric cover and flap
3. Have a triangular, circular, or square shaped cross section
4. Have a vertical height of at least 5 inches after installation
5. Have a horizontal flap of at least 8 inches in width
6. Have a length of at least 4 feet per unit
7. Have the ability to interlock separate units into a longer barrier so that water does not flow between the units
8. Be secured to:
 - 8.1. Pavement with 1-inch concrete nails with 1-inch washers and solvent-free adhesive
 - 8.2. Soil with 6-inch nails with 1-inch washers

Linear Sediment Barrier

Linear sediment barriers must consist of one or more of the following:

1. Silt fence
2. Gravel-filled bags
3. Fiber roll
4. Rigid plastic barrier
5. Foam barrier

Flexible Sediment Barrier

Flexible sediment barriers consist of one or more of the following:

1. Rigid plastic barrier
2. Foam barrier

Foam Barriers

If foam barriers are used as a linear sediment barrier:

1. Install barriers with the horizontal flap in a 3 inch deep trench and secured with nails and washers placed no more than 4 feet apart
2. Secure barriers with 2 nails at the connection points where separate units overlap
3. Place barriers without nails or stakes piercing the core

Flexible Sediment Barriers

If flexible sediment barriers are used:

1. Secure barriers to the pavement with nails and adhesive, gravel-filled bags, or a combination
2. Install barriers flush against the sides of concrete, asphalt concrete, or hot mix asphalt curbs or dikes
3. Place barriers to provide a tight joint with the curb or dike and anchored in a way that runoff cannot flow behind the barrier

If flexible sediment barriers are used for Type 4B:

1. Secure barriers to the pavement according to the angle and spacing shown on the plans
2. Place barriers to provide a tight joint with the curb or dike. Cut the cover fabric or jacket to ensure a tight fit

MAINTENANCE

Maintain temporary drainage inlet protection to provide sediment holding capacity and to reduce runoff velocities.

Remove sediment deposits, trash, and debris from temporary drainage inlet protection as needed or when directed by the Engineer. If removed sediment is deposited within project limits, it must be stabilized and not subject to erosion by wind or water. Trash and debris must be removed and disposed of as specified in Section 7-1.13, "Disposal of Material Outside the Highway Right of Way," of the Standard Specifications.

Maintain temporary drainage inlet protection by removing sediment from:

1. Behind flexible sediment barriers when sediment exceeds 1 inch in depth

If geosynthetic fabric becomes split, torn, or unraveled, repair or replace foam barriers.